
skymen

A6 Pro User Manual »


Intelligent ultrasonic cleaner



The picture is for reference only, please refer to the actual product

Please read the instruction manual carefully before use
Please keep this instruction manual properly

Product components and functions introduction



❶ Cover ❷ Stainless steel tank ❸ Maximum water line
❹ Power connector ❺ Control panel ❻ Power socket
❼ UV-C Light ❽ Body

Product technical parameter

Model	A6 Pro	Tanks size	177*81*45mm
Rated voltage	12V⎓2A	Product size	220*104*72mm
Capacity	550mL	Working time	3mins
Power	24W	Frequency	46KHz

Application

	Species	Species
Application	Optical	Glasses (no UV coating)
	Office supplies	Rulers, scissors, pens, etc.
	Daily necessities	Toothbrush, Shaver, comb, etc.
	Jewelry	Rings, necklaces, earrings, etc.
	Tableware supplies	Metal tableware, ceramic tableware, dentures, etc

	Species	Concrete example
Not Applicable	Wooden product	Turtle shell frame, pearls, Opal, emerald, coral, ivory, Emerald, stone, etc. Watch body (including waterproof watch), lacquerware.
	Gems with soft surface hardness	
	Inferior products for plating and finishing	
	Glued gems	
	Supplies with scratches and cracks	

Operating steps

⚠ The machine will be damaged if operate ultrasonic without water




Connect the power supply, the white light is on, and it enters the standby state. Open the upper cover, pour clean water into the stainless steel inner tank, and put the items to be cleaned into the water. (The parts that need to be cleaned are fully immersed in water, But the water level cannot exceed the maximum water level line "MAX-").



Touch the switch once to start the machine and enter the state of separate cleaning for 3 minutes. During the cleaning process, there will be a "sizzle" sound, the green light is on, And touch the switch during the cleaning process, the machine stops working, touch it again, and the cleaning continues.



Touch the switch once to start the machine, and enter the state of separate ultraviolet disinfection and sterilization for 3 minutes, the blue light is on, and touch the switch once during the cleaning process, the machine stops working, touch it again, and the work continues.



During ultrasonic cleaning, touch the switch once, ultrasonic and UV disinfection work at the same time. The working time of UV disinfection is 3 minutes from when UV disinfection is turned on. Ultrasonic cannot be turned on when UV disinfection t is working alone. When working at the same time, touch the switch once to turn off the ultrasonic and UV disinfection, and touch the switch once to turn off only the UV disinfection.



After cleaning, pour out the water in the stainless steel inner tank, and wipe the body and the stainless steel inner tank with a clean soft cloth. Store in a dry, flat place.

CAUTION:

When cleaning the glasses, place the lens facing up. Do not touch the stainless steel tank directly.

It is forbidden to directly add water to the tap, which may cause electric shock and malfunction.

The "sizzling" sound during the cleaning process is the sound of ultrasonic vibration, which is a normal phenomenon.

After each cleaning, be sure to pour out the water in the machine, even if the water is only used once.

In order to avoid malfunctions caused by overheating of the machine, when the machine is continuously used for multiple times, it should not exceed 15 minutes, and there must be a rest period in between.

Please do not disassemble the product easily if you are Non-professionals

Cleaning and Sterilization time

Application	Cleaning and Sterilization time
Glasses (no UV coating)	About 3 minutes
Rulers, scissors, pens, etc.	
Toothbrush, Shaver, comb, etc.	
Rings, necklaces, earrings, watch strap etc.	Note: Prolonged cleaning and disinfection may cause damage to items, The cleaning and disinfection process should not be too long.
Metal tableware, ceramic tableware, dentures, etc	

Problems that need to be paid attention to when cleaning

- It may not be able to completely remove tartar, sallow, dark spots, and smoking remaining etc in the dentures.
  It may not be possible to clean the sedatives fixed in the dentures.
- Discoloration and rusting of metals and metals cannot be removed.
- When cleaning necklaces/rings with gems/diamonds glued together, the gems/diamonds may fall off
- When cleaning the metal watchband, please remove the watchband from the main body of the watch before cleaning, only use cleaning fluid or cleaning water. Do not put the watch (including waterproof type) into the cleaner, it may cause the water enters inside the watch body and the ultrasonic vibration power causes damage to the internal parts of the watch body.
- When cleaning the glasses, the lens should be placed upward, and the cleaning time is 1-3 minutes.
  When cleaning stubborn stains, the cleaning solution can be evenly applied to the lens, and then put into the water, the cleaning effect is better.
- Since the coating technology has not yet broken through, the glasses with the lens filming or frame coating process, please first consult the optical shop to confirm whether it can be used for ultrasonic cleaning, so as to avoid unnecessary losses.

TIPS

Pearl jewelry, jade, gems with soft surface hardness; objects with serious cracks;
Products and wood products with poor plating and finishing are not suitable for cleaning with this product;
Whether Lacquerware and some valuables product can be cleaned, please consult before cleaning.

Safety Precautions

In order to avoid fire, electric shock, and personal injury, please be sure to comply with the following requirements; Or please follow the relevant national and local electrical regulations

1. Ultrasonic working environment: ambient temperature requirements 0℃-50℃
2. Cleaning fluid requirements: It is forbidden to use liquids that are corrosive to stainless steel and ABS plastics as cleaning fluids.The temperature of the lotion should not exceed 60°C.
3. The continuous working time of the machine shall not exceed 15 minutes, and there must be a break in between.
4. Requirements for placing the machine: if it will not be used for a long time, be sure to wipe the machine clean and make sure it is placed the place is not humid! Remember that there should be no liquid in the machine when it is stored.
5. This product cannot be used as a child's toy, and children are not allowed to use this product without supervision.

Cleaning and maintenance

When cleaning and maintaining, please disconnect the power plug first

Wipe the surface of the machine with a damp cloth, and then wipe off the water with a dry cloth.

Do not see water into the switch and power connection

WARRANTY CARD

Cause of issue	Maintenance records	Maintenance time

Warranty notes

Thank you very much for purchasing this product! The relevant certifications of our products are complete, and all products have been strictly tested before delivery From the date of purchase, we promises to provide "one-year warranty, lifetime maintenance" service, but the return freight is borne by the buyer, and the maintenance service outside the warranty scope will be charged according to the actual situation.

The following situations are not covered by the one-year free warranty:
1. Exceeding the warranty time; 2. All man-made damage; 3. Failure to operate, maintain, and keep in accordance with the product instruction manual causes damage; 4. The user disassembles the machine for maintenance without permission; 5. Without this warranty card or altering the warranty card without authorization; 6. The product model on the warranty card does not match the actual product;
7. Damage caused by force majeure during use, such as floods, earthquakes, etc.

Return & exchange Precautions

Please complete the return and exchange content, reason, model, purchase time, contact person, phone number,Consignee address, and strengthen the packaging before sending back. Please ensure that the packaging of the tank of the returned machine is complete and clean. If the tank or the appearance is dirty, scratched, deformed and other factors that affect the secondary sales, the return will not be refunded; if the product is damaged due to packaging problems, the warehouse will directly refuse the parcel. Also refuse to receive the parcel with freight collect, thank you for your cooperation!

Certificate of conformity

Product name : Intelligent ultrasonic cleaner

Model : A6 Pro

Inspectors : 6

Test result : 合格

Skymen Cleaning Equipment Shenzhen Co., Ltd

Office：3F, A1 Block, Fuhai Technology Park Building, FuYong Steet, baoan district, Shenzhen, Guangdong, China.
Factory：Skymen Ultrasonic, Wujiang Technology Industrial Park, Wujiang District, Shaoguan City, Guangdong, China.
Tel：0755- 27094405 Email：info@skymen.cc
website：www.skymen.cc

Solemnly declare

The company's products are constantly improving, and the design and specifications are subject to change without notice. All the information in this manual has been carefully proofread and strived to be accurate. If there are any printing errors or omissions, the company reserves the right of interpretation. The copyright of this manual belongs to Skymen Cleaning Equipment Shenzhen Co., Ltd., without written authorization, it is strictly forbidden to reprint or reprint, and the company will pursue its legal responsibility if it violates it.